

**PRINTING NOTE: SELECT PAGE SCALING FEATURE TO
"NONE"
PRINT 4 COPIES OF THIS PAGE & PASTE TOGETHER**

ACCESS DOOR

SIZE
16 X 12 X _____
DUCT DIAMETER

The template is self-adhesive. Remove the backing paper and place where required. Then once the template is pressed into position, cut the opening in the ductwork. To install the access door, first turn the knobs counter-clockwise as far as possible.

Then grip the knobs with both hands and push the access door into the duct opening in an angled position with the back plate inside the duct. And finally, align the back plate with the duct opening and tighten both knobs until the gasket provides an air-tight seal.

5.63

7.78